




# Pressure Mat Connections



## Notes

- The Pressure Mat accessory requires one connection to ground and one connection to an Input.
- The input pins on the BRNKL's green connector span from Pin 4 through Pin 7, which represent Input 1 to 4.
- It does not matter which of the two wires go to ground and to the BRNKL Input.
- Connect ground wire to any common ground terminal.