




Laser Sensor (12 m / 50 ft) Connections



LI20C-1007-022

Terminal	Connection
A blue	Common ground
B black	BRNKL connector Slot 9
C brown	BRNKL connector Slot 10
D blue	Common ground
E brown	12-24V DC fuse-protected power
F violet	no connection



Get more help at brnkl.io/help

