











Laser Sensor | 6 m / 20 ft

Connections



L6C-1007-023

Terminal	Connection
A  Blue	 Common ground
B  Black	 BRNKL connector Slot 9 *
C  Brown	 BRNKL connector Slot 10



* Connect any shore power sensor to an alternate slot.
See *Shore Power Connections* for details.

Get more help at brnkl.io/help

