








# Shore Power Sensor | Plug-in Connections



SPP-1007-023

Terminal	Connection
<b>A</b>  Red	 BRNKL connector <span>Slot <b>9</b></span>
	<span>Slot <b>11 12 13</b></span> Alternate
	<span>Slot <b>4 5 6 7</b></span> via DC Device Controller
<b>B</b>  Black	 Common ground

Get more help at [brnkl.io/help](https://brnkl.io/help)

