













# DC Relay | 12 V

## Connections



DCR12-1007-023

Terminal	Connection
<b>A</b>  blue	 BRNKL connector <span>Slot <b>4 5 6 7</b></span>
<b>B</b>  black	 Common ground
	 Bilge switching lead
<b>C</b>  white	 Ignition switching lead
	 Shore Power Sensor <span> + Vo</span>


Get more help at [brnkl.io/help](https://brnkl.io/help)












# DC Relay | 24 V

## Connections



DCR24-1007023

Terminal	Connection
<b>A</b>  blue	 BRNKL connector Slot <b>4 5 6 7</b>
<b>B</b>  black	 Common ground
<b>C</b>  white	 Bilge switching lead
	 Ignition switching lead

Get more help at [brnkl.io/help](https://brnkl.io/help)

